



## WOOD WINDOW ROUGH OPENINGS

				UNITS WITH TRANSOMS				4" SPREAD VERT MULLS		
SIZE	SINGLE	TWIN	TRIPLE	10" TRANS HEIGHT	12" TRANS HEIGHT	SINGLE TRUE RADIUS	TWIN TRUE RADIUS	SIZE	TWIN	TRIPLE
2/0 X 3/2	26X42	51-1/2 X 42	77X42	53	55	55	68	2/0 X 3/2	54X42	82X42
2/0 X 3/10	26X50	51-1/2 X 50	77X50	61	63	63	76	2/0 X 3/10	54X50	82X50
2/0 X 4/6	26X58	51-1/2 X 58	77X58	69	71	71	84	2/0 X 4/6	54X58	82X58
2/0 X 5/2	26X66	51-1/2 X 66	77X66	77	79	79	92	2/0 X 5/2	54X66	82X66
2/0 X 6/2	26X78	51-1/2 X 78	77X78	89	91	91	104	2/0 X 6/2	54X78	82X78
2/4 X 3/2	30X42	59-1/2 X 42	89X42	53	55	57	72	2/4 X 3/2	62X42	94X42
2/4 X 3/10	30X50	59-1/2 X 50	89X50	61	63	65	80	2/4 X 3/10	62X50	94X50
2/4 X 4/6	30X58	59-1/2 X 58	89X58	69	71	73	88	2/4 X 4/6	62X58	94X58
2/4 X 5/2	30X66	59-2/2 X 66	89X66	77	79	81	96	2/4 X 5/2	62X66	94X66
2/4 X 6/2	30X78	59-2/2 X 78	89X78	89	91	93	108	2/4 X 6/2	62X78	94X78
2/8 X 3/2	34X42	67-1/2 X 42	101X42	53	55	59	76	2/8 X 3/2	70X42	106X42
2/8 X 3/10	34X50	67-1/2 X 50	101X50	61	63	67	84	2/8 X 3/10	70X50	106X50
2/8 X 4/6	34X58	67-1/2 X 58	101X58	69	71	75	92	2/8 X 4/6	70X58	106X58
2/8 X 5/2	34X66	67-1/2 X 66	101X66	77	79	83	100	2/8 X 5/2	70X66	106X66
2/8 X 6/2	34X78	67-1/2 X 78	101X78	89	91	95	112	2/8 X 6/2	70X78	106X78
3/0 X 3/2	38X42	75-1/2 X 42	113X42	53	55	61	80	3/0 X 3/2	78X42	118X42
3/0 X 3/10	38X50	75-1/2 X 50	113X50	61	63	69	88	3/0 X 3/10	78X50	118X50
3/0 X 4/6	38X58	75-1/2 X 58	113X58	69	71	77	96	3/0 X 4/6	78X58	118X58
3/0 X 5/2	38X66	75-1/2 X 66	113X66	77	79	85	104	3/0 X 5/2	78X66	118X66
3/0 X 6/2	38X78	75-1/2 X 78	113X78	89	91	97	116	3/0 X 6/2	78X78	118X78

				UNITS WITH TRANSOMS		
SIZE	SINGLE			HEIGHT	HEIGHT	TRUE RADIUS
4/0 X 3/2	50X42			53	55	67
4/0 X 3/10	50X50			61	63	75
4/0 X 4/6	50X58			69	71	83
4/0 X 5/2	50x66			77	79	91
4/0 X 6/2	50x78			89	91	103
5/0 X 3/2	62x42			53	55	73
5/0 X 3/10	62x50			61	63	81
5/0 X 4/6	62x58			69	71	89
5/0 X 5/2	62x66			77	79	97
5/0 X 6/2	62x78			89	91	109
6/0 X 4/6	74x58			69	71	89
6/0 X 5/2	74x66			77	79	97
6/0 X 6/2	74x78			89	91	109

Rough openings are calculated by adding 2" to sash width, 4" to sash height, and 1/2" for each mull.

Spread mull means the total width of the mull, not the pocket between the mull. A 4" spread mull has a 2-1/2" pocket between the jambs.