



EXTERIOR DOOR ROUGH OPENINGS

6/8 DOOR UNITS		UNITS WITH TRANSOMS			
		10" TRANS HEIGHT	12" TRANS HEIGHT	14" TRANS HEIGHT	TRUE RADIUS TRANS
2/8 X 6/8 SINGLE HUNG	34 X 82-1/2	34X94	34X96	34X98	38 X 98-1/2
3/0 X 6/8 SINGLE HUNG	38 X 82-1/2	38X94	38X96	38X98	38 X 102-1/2
5/0 X 6/8 DOUBLE HUNG	63 X 82-1/2	63X94	63X96	63X98	63X115
5/4 X 6/8 DOUBLE HUNG	67 X 82-1/2	67X94	67X96	67X98	67X117
6/0 X 6/8 DOUBLE HUNG	75 X 82-1/2	75X94	75X96	75X98	75X121
10", 3/0, 10" X 6/8 ENTRANCE FRAME	61-1/2 X 82-1/2	62X94	62X96	62X98	62 X 114-1/2
12", 3/0, 12" X 6/8 ENTRANCE FRAME	65-1/2 X 82-1/2	66X94	66X96	66X98	66 X 116-1/2
5/0 X 6/8 ATRIUM CENTER HINGE/PATIO SIDE HINGE	64 X 82-1/2	64X94	64X96	64X98	
5/4 X 6/8 ATRIUM CENTER HINGE/PATIO SIDE HINGE	68 X 82-1/2	68X94	68X96	68X98	
6/0 X 6/8 ATRIUM CENTER HINGE/PATIO SIDE HINGE	76 X 82-1/2	76X94	76X96	76X98	

8/0 DOOR UNITS	
2/8 X 8/0 SINGLE HUNG	34 X 98-1/2
3/0 X 8/0 SINGLE HUNG	38 X 98-1/2
5/0 X 8/0 DOUBLE HUNG	63 X 98-1/2
5/4 X 8/0 DOUBLE HUNG	67 X 98-1/2
6/0 X 8/0 DOUBLE HUNG	75 X 98-1/2
10", 3/0, 10" X 8/0 ENTRANCE FRAME	61-1/2 X 98-1/2
12", 3/0, 12" X 8/0 ENTRANCE FRAME	65-1/2 X 98-1/2

Rough openings are calculated by adding 2" to width and 2-1/2" to height.

Spread mull means the total width of the mull, not the pocket between the mull. A 4" spread mull has a 2-1/2" pocket between the jambs.

For outswing doors, subtract 1" from all heights.